



Electric Chain Hoist

Operation Manual & Parts List

Series:

- ☐ YSTU(D)-300
- ☐ YSTU(D)-500



CHENG DAY MACHINERY WORKS CO., LTD.

SAFETY-IMPORTANT

The use of any hoist and trolley presents some risk of personal injury or property damage.

That risk is greatly increased if proper instructions and warnings are not followed. Before using this hoist, each user should become thoroughly familiar with all warnings, instructions and recommendations herein.



This symbol points out important safety instructions which if not followed could endanger the personal safety and or property of yourself and others.

Read and follow all instructions in this manual and any provided with the equipment before attempting to operate your electric chain hoist.



Contents

Safety — Important	1
1.Foreword	3
2.Main Specification	4
2.1 Specification	4
2.2 Mechanical Classification (Grade) And Life	5
2.3 Safety Device	6
2.4 Main Specification And Dimensions	7
3.Safety Rules	8
4.Installation	10
4.1 Unpacking Information	10
4.2 Voltage	10
4.3 Installation	10
5.Operation	13
6.Maintenance And Inspection	13
6.1 Maintenance	13
6.2 Inspection	14
7.Troubleshooting	18
7.1 Wiring Diagrams	18
7.2 Troubleshooting And Remedial Action	20
8.Drawings And Parts Lists	21
9. The Standard Instruction And Inspection For Chain Block	38
10. Inspection List	39

1. Foreword


This manual contains important information to help you properly install, operate and maintain the electric chain hoist for maximum performance, economy and safety.

Please study its contents thoroughly before putting the electric chain hoist into operation. By practicing correct operation, procedures and by carrying out the preventative maintenance recommendations, you will be assured of dependable service. In order to help us to supply correct spare parts quickly, please always specify,

- (1) Hoist model
- (2) Serial number
- (3) Part number, plus the description.

We will have your trust of Cheng Day's long term satisfactory service as our belief.

Should you have any queries, please contact:



(Please ask for a company's stamp from your local agent.)

2. MAIN SPECIFICATION

2.1 Specification

The following specifications are common to all electric chain hoists.

Table 2-1 Specifications

Item		Detail	
Working temperature range(°C)		-5 to +40	
Working humidity range (%)		85 or less	
Protection(Option)	Hoist	IP 42	
	Push button	IP 65	
Electric power supply		Three Phase, 220V~600V,50Hz,60Hz	
Noise Level (dB)	Single speed hoist	81	
	Dual Speed hoist	81	
Chain size	WLL (working load limit)(t)	Nominal diameter (mm)	Pitch (mm)
	3T	10.0	30.2
	5T	11.2	34

Remarks :

- (1)Contact an authorized dealer for information on using the hoist over the working temperature or humidity range.
- (2)For dimensions and other details, refer to the latest catalogue.
- (3)Noise levels were measured at a distance of 1m horizontally from the hoists during normal operation.

2.2 Mechanical Classification (Grade) and Life


Safety and life for electric chain hoists are guaranteed only when the said equipment is operated in accordance with the prescribed grade.

Electric chain hoists have been designed for grade 2m except YSF-series 1Dm in the FEM regulations (FEM 9.511). Details are provided in Table 2-2.


Average daily operating time and total operating time are determined by load distribution.

Table 2-2 Mechanical classifications


Load Spectrum (Load distribution)	Definitions	Cubic mean value	1Dm	2m
			Average daily operating time (h)	Average daily operating time (h)
			Total operating time (h)	Total operating time (h)
1 (light)	Mechanisms or parts thereof, usually subject to very small loads and in exceptional cases only to maximum loads.	$k \leq 0.50$	0.25-0.5	4-8
			800	12500
2 (medium)	Mechanisms or parts thereof, usually subject to small loads but rather often to maximum loads.	$0.50 < k \leq 0.63$	0.12-0.25	2-4
			400	6300
3 (heavy)	Mechanisms or parts thereof, usually subject to medium loads but frequently to maximum loads.	$0.63 < k \leq 0.80$	≤ 0.12	1-2
			200	3200
4 (very heavy)	Mechanisms or parts thereof, usually subject to maximum or almost maximum loads.	$0.80 < k \leq 1.00$	-	0.5-1
			-	1600




% operating time
Load spectrum 1



% operating time
Load spectrum 2



% operating time
Load spectrum 3



% operating time
Load spectrum 4

2.3 Safety Devices

(1) Motor brake

“Electro-Magnetic Brake” is of a unique design in its field. It features simultaneous motor braking upon switching off power even under full load condition.

(2) Mechanical load brake

The mechanical load brake can hold a full capacity load independent of motor brake.

This brake assures that load does not accelerate while being lowered.

(3) Hook and hook latch

The hook is drop-forged from high tensile steel and heat treated for strength and Toughness. The bottom hook is capable of 360° swivel and fitted with safety latch to ensure safe lifting.

(4) Phase error relay

The Phase error relay circuit has been exclusively developed to prevent motor from running when the phase are incorrectly connected.

(5) Limit Switches


Upper and lower limit switches are fitted for switching off power automatically in case of over lifting or over lowering.

(6) Emergency stop device (optional)

This button is used to stop the hoist in an emergency situation. It is a red, Mushroom type button, located at the uppermost position of the pendant. When pressed, power to the equipment is switched off and the button locks automatically.

Turning it to the right will release the lock and enable re-starting.

(Illust.1)



Illust.1


2.4 Main Specification and Dimensions

■ Main Specification

Model	Capacity (ton)	Fall No.	Hoisting			Traversing			Flange Width (mm) T	N.W (kg)
			Speed (m/min)		Motor kw pole	Speed (m/min)		Motor kw pole		
			50Hz	60Hz		50Hz	60Hz			
YSTU-300	3	2	4.3	5.2	3.7 4P	20	24	0.4x2 4P	125~ 175	593
YSTUD-300			4.3/1.4	5.2/1.7	3.7/1.2 4/12P	20/6.7	24/8	0.4/0.13x2 4/12P		
YSTU-500	5	2	2.7	3.2	3.7 4P	20	24	0.4x2 4P	125~ 175	627
YSTUD-500			2.7/0.9	3.2/1.1	3.7/1.2 4/12P	20/6.7	24/8	0.4/0.13x2 4/12P		

■ Dimensions

Model	Capacity (ton)	Fall No.	Dimension(mm)												
			H	A	B	C	D	F	J	K*	L*	M*	N	Q	R
YSTU-300	3	2	280	395	160	569	324	57	227	925	240	645	565	352	416
YSTUD-300															
YSTU-500	5	2	330	395	160	569	324	57	227	864	123	534	580	366	430
YSTUD-500															



3. SAFETY RULES

DANGER

The hoist herein is not designed for, and should not be used for, lifting, supporting, or transporting personnel. Any modifications to upgrade, re-rate, or otherwise alter the hoist equipment must be authorized by either the original manufacturer or a qualified professional engineer.

(1) Only the trained personnel are allowed to operate the hoist.

(2)


DANGER

Do not use the hoist in explosive atmosphere.

(3) Prior to each lifting operation, it is essential to make sure that:

(a) The correct lifting sling is being used.

(b) The lifting sling is located in the hook as shown below (Illus. 2) and that a safety latch has been fitted.



Illus. 2


(c) The object to be hoisted is well secured for direct lifting (a proper lifting frame or apparatus is strongly recommended for direct lifting.)

(4) Firm and steady button operation is required, never push the button switch intermittently.


(5) Always avoid excessive inching operation.

(6) Always make sure the hoist motor completely stops before reversing.

- (7) Always leave the push button switch cable and bottom hook vertically static after completion of operation, never leave them at any position which may cause swing or slip.
- (8) Sling must be applied to load evenly and centrally to ensure correct balance. Never lift any object which is insecure or out of balance.
- (9) Never use hoist to end or side pull a load. (Illus. 3)
- (10) Never wrap around and hook back the load chain as a sling to lift a load. (Illus. 4)



Illus. 3



Illus. 4

(11)


! WARNING

Do not use the hoist chain as a welding electrode.

(12)

! DANGER

Never stand under a raised load (Illus. 5)



Illus. 5

- (13) Lifting must always be personally attended, never leave a raised load unattended.
- (14) Over-capacity-load lifting is hazardous and should not be undertaken.
- (15) Never lift a load when the load chain is twisted.
- (16) Regularly inspect and check the condition of load chain. Do not operate with damaged chain.

4. INSTALLATION

4.1 Unpacking Information

After removing the hoist from its packing box, carefully inspect the external condition of the electrical cables, contactor, gearbox and motor casing for damage.

Check and ensure that these items are present.

Each hoist is supplied as standard with the following accessories:

1.Chain bucket	1 set
2.Power cable	3 meters
3.Push button control switch	1 piece

Table 4-1

4.2 Voltage

CAUTION

If power supply deviates from standard by more than $\pm 10\%$ abnormal operation or damage to the motor may result. It is imperative to ensure correct voltage supply before commencing operation.

4.3 Installation


WARNING

Connection to power supply before installation procedures having been completed is strictly prohibited.

(1) Prior to installation check and ensure that the top hook assembly is securely attached to the hoist by means of the connecting pin (page 35, item 13)


NOTE : If the hoist is to be suspended from an electric trolley, assembly may be eased by firstly removing the top hook, just attaching hoist top hook to the trolley load plate.

(2) Assemble chain bucket.







Illus. 6

(3) Connect power supply to hoist and operate the push button switch. This operation must be carried out by a trained person .




Illus. 7

(4) Operation Test


- (A) Firmly push  switch button to lower load chain until the limit spring touches the limit switch. Power should be cut off automatically.
- (B) Firmly push  switch button to check the collection of load chain into chain bucket.
- (C) Check the emergency stop device function (if fitted):
While holding down either  or  button on the push button switch, push the emergency stop button. Check that the hook stops when the emergency stop button is pushed. Also, check the hoist does not move in response to the push button switch. Finally, check that the emergency stop device pops out when turned to the right and that operation can be resumed thereafter. If the equipment fails to pass another above checks, check the wiring and automatic locking function of the emergency stop device.
- (D) Check load chain lubrication (It has been lubricated at our works, but the lubricant may dry out during transportation). Any readily available lubricant is recommended. It is further advisable to keep a small amount of lubricant in chain bucket to allow chain in oil bath.
- (E) Check chain position. Weld joints on links must face the same direction (Illus. 8), correct chain operation can only be achieved when all joints are vertically in line.

CAUTION

The bottom hook on multi-fall hoist must never be rotated as shown below (Illus. 9).



Illus. 8



Illus. 9

5. OPERATION

After running test and checks have been completed, the hoist will be ready for normal operation.

WARNING

Since dealing with heavy loads may involve unexpected danger, all of the "SAFETY RULES" (Ref 3.) must be followed and the operator must be aware of the following points while using the hoist.

- (1) The operator must have a clear and unobstructed view of the entire working area before operating the hoist.
- (2) The operator must check that the entire working area is safe and secure before operating the hoist.
- (3) When using the hoist with a motorized trolley, the operator must take care to prevent excessive load swinging by sympathetic use of the trolley controls.

6. MAINTENANCE AND INSPECTION

DANGER

Do not perform maintenance on the hoist while it is carrying a load except monthly checking for the brake or limit switch.

DANGER

Before performing maintenance do not forget to affix tags to the power source and the push button switch reading: "DANGER", "EQUIPMENT BEING REPAIRED".

6.1 Maintenance

- (1) Check the level of gear box lubricant after the first 500 hours operation, thereafter check every 3 months and lubricate accordingly.
NOTE: WE RECOMMEND USING A LUBRICANT OIL EQUIVALENT TO ISO VG460.
- (2) Always keep the hoist unit dry and never misuse it in a manner likely to reduce its durability.
- (3) When it is necessary to keep the unit outdoors, a protective covering should be fitted.

6.2 Inspection

(1) Daily inspection: Before starting daily operation, check the following

- (a) Correct power supply.
- (b) "Up", "Down" and "Emergency stop" (where fitted) test runs under no load.
- (c) Correct motor performance.
- (d) No abnormal or excessive noise.
- (e) No malfunction of the bottom hook safety latch.
- (f) Proper function of moving/turning parts, limit switches and brake.
- (g) Well lubricated load chain.

(2) Monthly inspection


(a) Load chain :

Chain Wearing Test

Load Spectrum	Cubic mean Value	Using times	
		Non-lubricated	Lubricated
1 (Light)	50%	44000	120000
2 (Medium)	63%	22000	60000
3 (Heavy)	80%	11000	30000
4 (Very heavy)	100%	5500	15000

Above testing data under lifting height 1M

1M pinpoint wearing test(100%Capacity)




Number of cycles (Lifting + lowering)

! WARNING

Always use the hoist manufacture's recommended parts when repairing a hoist.

Distorted, elongated or worn chain link will not sit properly on the load sprocket wheel and may cause chain breakage and/or damage to the hoist unit. To ensure safe and efficient operation, the chain links must be checked for their pitch (inside length), inside width and outside width monthly according to following table.




Dia-Meter (m/m) (d)	Load (ton)	Inside Length (m/m) (p)	Inside Width (m/m) (b1)	Outside Width (m/m) (b2)	Breaking Load (kN)
10.0	3T	30.2	12.5	33.2	128
11.2	5T	34	14	37.5	160

Table 6-2-a

(b) Load hook:

Check hook with care. If hook shows crack deformation or wear in excess of 5% of its original size, it should be replaced (Ref. following table)



Capacity (ton)	Dimensions (mm)									Allow Stress (kg/mm ²)
	H1	B1	B2	H2	B3	B4	C	G	E	
3	55	34	19	48	34	19	52	40	90	70
5	66	44	23	60	44	23	62	45	100	70

Table 6-2-b

(c) Limit Switches :



A qualified electrician should perform this inspection.

Check correct operation of the limit switches. Clean thoroughly and apply a thin lubrication to ensure correct operation.

(3) Annual inspection



Your dealer should be asked to perform this inspection.

- (a) Check gearing for any excessive wear or damage.
- (b) Replace gearbox lubricant completely (1400 C.C~1500C.C $\pm 10\%$), as following table for your reference Table 6-2-c.
- (c) Check brake lining and ratchet pawl for any wear or damage.
- (d) Check operation of pawl spring.
- (e) After reassembly of above check, lifting a load several times to ensure good performance of the hoist before starting duty operation.

※ Oil Quality Table

For Load Chain / All Model						
Model	Lubricate Method	Lubricant Adding		Lubricant Changing		Recommended oils
		Period	Q'ty / c.c.	Period	Q'ty / c.c.	
All Model	Smear oil on load chain surface	Weekly	-	-	-	ISO VG460
All Gear Box	Soak in oil	Monthly	Suitable	Annual	1400 ~ 1500	ISO VG460

※ Table of recommended oils

ISO-VGDIN 51519 viscosity At 40°C mm ² /s (cST)	Approximate viscosity of the VG Categories 50°C mm ² /s (cST)	ARAL	BP	ESSO	MOBIL OIL
VG460	251	Aral Degol BG 460-BMB 460	BP Energol GR-XP 460	Spartan EP-460	Mobilgear 634

ISO-VGDIN 51519 viscosity At 40°C mm ² /s (cST)	Approximate viscosity of the VG Categories 50°C mm ² /s (cST)	SHELL	TEXACO	I.P.	AGIP	TOTAL
VG460	251	Omala oil 460	Meropa 460	Mellana 460	Blasia 460	Carter EP 460

Table 6-2-c

Chain Gauge — Wear and Stretch Measuring

- (1) The chain gauge is useful and convenience for measuring.
- (2) Please use a chain gauge to measure the chain pitch and diameter, such as illustrations (1) and (2).
- (3) Every chain ring must be measured , and the chain must be replaced when one of chain rings is wear or stretch.
- (4) It will be a cutting-out possibility if you use a chain fall either wear or stretch during operation.
- (5) Do not replace a chain fall by yourself and do please contact specific either service centers or contractors to help you out.
- (6) The chain fall must be replaced whole instead of a partial part.
- (7) The load sheave, regulator, and chain compressing wheel must be replaced the same time as you do a second time replacement.

Remark

- (1) Chain must be perfect condition without any defects and attachments.




Illustration (1)
Chain pitch measure




Illustration (2)
Diameter measure

7. TROUBLESHOOTING

7.1 Wiring Diagrams

- (1)A50041A-1RM021 : YSTU series, single speed wiring diagram 19
- (2)A80018-1RM : YSTUD series, dual speed wiring diagram 19

The above models are available in the following specification :

- (a) 3-Phase
- (b) 50 or 60 Hertz
- (c) Single and dual voltage


Voltage Hertz	Dual Voltage	Single Voltage
50 Hz	220V/380V 220V/440V	220V to 600V
60 Hz	230V/460V	

Table 7-1


Warranty Details

1. Warranty Period : One year for Mechanical Spare Parts after purchase the product.
2. Non-Warranty Scope :
 - a. Electrical Spare Parts (ex. Contactor, Pendant, Phase Error Relay, etc.)
 - b. Expense Spare Parts (ex. Chain Bucket, Brake Lining, etc.)
 - c. Damage caused by unsuitable operation.
(ex. Galvanize plant, Chemical Plant, Dye-work, etc.)
 - d. Damage caused by operating on the wrong electric voltage.
 - e. Damage caused by user amend the product.
 - f. Damage caused by natural disaster.
3. Warranty Scope shall be permitted by Cheng Day Machinery and Within One Year of damaged Mechanical Spare Parts Repair and Replacement.
(circumstance stated in detail No. 2 are not included.)

CHAIN HOIST FOR SINGLE SPEED 380V- 48V



CHAIN HOIST FOR DUAL SPEED 380V- 48V




7.2 Troubleshooting and Remedial action

SITUATION	CAUSE	REMEDY
Hoist will not operate	(1) Phase error relay operated due to incorrect phase connections	Reverse any two phase connections.
	(2) Blown power fuse or tripped power circuit breaker	Check supply requirements and replace the fuse/reset breaker to meet requirements.
	(3) Blown control circuit fuse	Check fuse for correct rating and replace
	(4) Broken/disconnected power or control circuit wire	Locate and repair/reconnect
	(5) Low supply voltage	Check if 10% reduction of voltage, have mains supply checked.
	(6) Motor hums but does not rotate	Check phases of motor - insulate and repair.
	(7) Emergency stop button release pushed (if fitted)	Check the cause as necessary
	(8) Faulty contactor	Operate manually if hoist runs then control circuit/coil is faulty - locate fault and repair. If hoist does not run then check main supply. If input supply is correct but there is a faulty output supply then replace the contactor
Hoist will not stop	Welded contacts in contactor	Replace contactor
Brake slips	Abrasion of motor brake	Replace
Abnormal sound. on load chain/ chain sprocket	(1) Chain dry	Lubricate
	(2) Worn chain sprocket	Replace load chain and chain sprocket
Electric shock	(1) Poor earth connection	Provide correct earth connection
	(2) Accumulated foreign matter/moisture on electrical parts	Remove foreign matter/dry electrical parts
Oil leak	(1) No oil plug	Attach the normal oil plug
	(2) Oil plug loosen	Fasten the plug tightly
	(3) No plug packing	Attach normal packing
	(4) Worn or deteriorated oil packing	Attach the new packing

8. Drawings and parts list

(1) Motor Assembly & Housing Drawing	22
(2) Motor Assembly & Housing B.O.M	23
(3) Bottom Hook Assembly Drawing.....	26
(4) Bottom Hook Assembly B.O.M	27
(5) Reducing Gear Box Drawing	28
(6) Reducing Gear Box B.O.M	29
(7) Load Chain Section Drawing	30
(8) Load Chain Section B.O.M	31
(9) Electric Parts Drawing	32
(10) Electric Parts B.O.M	33
(11) Low Headroom Model's Drawing	34
(12) Low Headroom Model's B.O.M	35

Motor Assembly & Housing Drawing



Motor Assembly & Housing B.O.M

S : Single Speed D : Dual Speed

Key No.	Parts Code	Description	Q'ty Req'd	
			3T,5T	
			S	D
1	400014	Hex. Recess Bolt <M8×1.25×30L>		4
2	400095	Spring Washer <M8>	14	18
3	106022	Motor End Cover	1	
	100424			1
4	100495	Brake Gap Adjuster	-	1
5	100395	Brake Drum	1	
	100409	Bauer Disc Spring		1
6	100490	Spacer Sleeve	1	
	100406	Brake Lining		1
7	400237	Brake Spring	1	
	400239			6
8	105981	Magnet Producer	1	
	100498	Magnet Coil Ass'y		1
9	400193	Retaining Ring <S-30>	-	1
10	400113	Bearing <6206 2RU>	1	
11	400200	Retaining Ring <R-62>	1	
12	100325	Motor Rotor	1	
	100375			1
13	400006	Hex. Recess Bolt<M6×1.0×16L>	-	3
14	400094	Spring Washer <M6>	4	15
15	400006	Hex. Recess Bolt <M6×1.0×16L>	-	8
16	400264	Rubber Cap	1	-
17	400220	Castle Nut <AN06>	1	-
18	400221	External Tooth Washer <AW06>	1	-
19	100430	Bearing Stop Ring	2	-
20	400023	Hex. Recess Bolt <M12×1.75×35L>	4	-
21	400097	Spring Washer <M12>	12	
22	100363	Motor Shaft Spacer	2	-
23	100365	Motor Retaining Ring	1	-
24	100410	Cone Spring	1	-
25	400218	Eye Bolt <M10×1.5>		
26	400585	Bolt <M8×1.25×16L>	2	
27	A	Motor Stator Ass'y	1	
	B			1

Motor Assembly & Housing B.O.M

S : Single Speed D : Dual Speed

Key No.	Parts Code	Description	Q'ty Req'd	
			3T;5T	
			S	D
28	402507	Gasket 7#	1	
29	400084	Nut <M12 × 1.75>	4	
30	207448	Motor Front Plate Ass'y	1	
31	209510	Connecting Screws Sleeve	4	
32	200698	Load Sheave Housing	1	
33	210139	Gasket 55#	1	
34	207504	Gear End Plate	1	
35	400032	Hex. Bolt <M12 × 1.75 × 120L>	4	
36	402510	Gasket 10#	1	
37	400021	Hex. Recess Bolt <M12 × 1.25 × 25L>	4	
38	400215	Spring Pin <Ø12 × 14L>	4	
39	200245	Gear Box A	1	
40	400025	Hex. Recess Bolt <M8 × 1.25 × 30 L>	6	
41	402511	Gasket 11#	1	
42	400219	Eye Bolt <M16 × 1.5>	1	
43	400227	Gasket Ring	1	
44	200926	Hex. Oil Plug	1	
45	200927	Air Plug	1	
46	400212	Spring Pin < Ø5 × 16L>	1	
47	402522	Gasket 22#	1	
48	300764	Electric Housing	1	
49		Name Plate	1	
50	300523	Lubricant Drain Bolt	1	
51	265666	Gear Box B	1	
52	400460	Hex. Recess Bolt <M8 × 1.25 × 65L>	8	
53	400005	Hex. Recess Bolt <M6 × 1.0 × 12L>	8	
54	400661	Flat Washer <M4>	2	
55	406412	Lock Nut <M4 × 0.7>	2	
56	408449	Hex. Recess Bolt <M4 × 0.7 × 20L>	1	
57	400559	Bucket Chain <Ø2.6 × 23.2 × 9.5-7>	1	
58	405026	Hex. Recess Bolt <M4 × 0.7 × 14L>	1	
59	402582	Gasket 67#	-	1
60	300801	Cable Fixing Plate	-	1


Motor Assembly & Housing B.O.M

S : Single Speed D : Dual Speed

Key No.	Parts Code		Description	Ø - HZ - V	
27	A	132701	Motor Stator Ass 'y (S)	3Ø 60HZ	220 / 380V
		132702			220 / 440V
		132707			230 / 460V
		132708			400V
		132706			600V
		132711		3Ø 50HZ	220 / 380V
		132712			400V
		132713			415V
		132714			525V
	B	132801	Motor Stator Ass 'y (D)	3Ø 60HZ	220V
		132802			230V
		132803			380V
		132804			460V
		132805			600V
		132811		3Ø 50HZ	220V
		132812			380V
		132813			415V
		132814			525V

※ For others voltage please contact with dealer for correct part no.


Bottom Hook Assembly Drawing



Bottom Hook Assembly B.O.M

Key No.	Parts Code	Description	Q'ty Req'd	
			3T	5T
1	207373	Bottom Hook Housing B	2	
	207495	Bottom Hook Housing B		2
2	408052	Needle Bearing < TA 3020Z >	4	
	400174	Needle Bearing <TA 4025 Z>		4
3	200170	Sprocket <Ø40 × 42L>	2	
	200111	Sprocket <Ø50 × 51L>		2
4	400212	Spring Pin <Ø5 × 16L>	2	2
5	200813	Idle Wheel Axle	2	
	200116			2
6	207372	Bottom Hook Housing A	2	
	207494			2
7	400096	Spring Washer <M10>	6	6
8	400432	Hex. Recess Bolt <M10 × 1.5 × 65>	4	
	400020	Hex. Recess Bolt <M10 × 1.5 × 50>		4
9	400019	Hex. Recess Bolt <M10 × 1.5 × 45>	2	
	400020	Hex. Recess Bolt <M10 × 1.5 × 50>		2
10	400105	Spring Washer <1 1/4" >	4	
	400654	Spring Washer <M42>		4
11	202011	Nut < 1 1/4" × 7UNC >	4	
	406430	Nut <M42 × 4.5>		4
12	207378	Stay Bolt <1 1/4" × 7UNC × 565>	2	
	207555	Stay Bolt <M42 × 4.5 × 580>		2
13	207376	Washer <t13 × 60 × 150>	6	
	207502	Washer <t13 × 76 × 210>		4
14	207374	Bottom Hook Housing C	2	
	207496			2
15	200133	Bottom Hook Retaining Ring	1	
	200134			1
16	400159	Thrust Bearing <51106>	1	
	400160	Thrust Bearing <51207>		1
17	200129	Bottom Hook Half Spacer	2	
	200130			2
18	209355	Bottom Hook	1	
	209358			1
19	400489	Safety Latch Ass'y	2	2
20	207379	Limit Plate	1	1
21	400094	Spring Washer <M6>	2	2
22	400005	Hex. Recess Bolt <M6 × 1.0 × 12>	2	2


Reducing Gear Box Drawing



Reducing Gear Box B.O.M

Key No.	Parts Code	Description	Q'ty Req'd	
			3T	5T
1	400140	Bearing <6009ZZ>	1	1
2	400201	Retaining Ring <R-75>	1	1
3	407841	Bearing <6210Z>	1	1
4	200695	Front Motor Axle Ass'y	1	1
5	404488	Oil Seal <Ø25 × Ø40 × 8>	1	1
6	200198	Load Sheave	1	
	200199			1
7	400185	Oil Seal < Ø58 × Ø80 × 12>	1	1
8	405567	Bearing <6010>	1	1
9	200286	Ratchet Pawl Shaft	1	1
10	400241	Ratchet Spring	1	1
11	200288	Ratchet Pawl	1	1
12	400190	Retaining Ring <S-16>	1	1
13	200699	Compress Retaining Sleeve	1	1
14	407772	Bearing <6405>	1	1
15	200734	3 rd Gear Ass'y	1	
	200735			1
16	200741	Ratchet Wheel Ass'y	1	1
17	200665	2 nd Gear	1	1
18	200274	Half Spacer	2	2
19	200277	Bearing Spacer	1	1
20	407746	Bearing <6304>	1	1
21	200265	4 th Gear	1	
	200267			1
22	400197	Retaining Ring <S-50>	1	1
23	400135	Bearing <6303>	1	1


Load Chain Section Drawing



Load Chain Section B.O.M

Key No.	Parts Code	Description	Q'ty Req'd	
			3T	5T
1	408576	Hex. Bolt <M16×2.0×140L>	3	3
2	207451	Sleeve A <Ø19×Ø27×63L>	3	3
3	400648	Lock Nut <M16×2.0>	3	3
4	400029	Hex. Bolt <M10×1.5×120L>	2	2
5	207452	Sleeve B <Ø12×Ø17×64.5L>	2	2
6	400089	Lock Nut <M10×1.5>	3	3
7	404630	Hex. Bolt <M10×1.5×100L>	1	1
8	207453	Connecting Plate	2	2
9	200203	Chain Regulating Plate <t2.0×50×160L>	1	1
10	400005	Hex. Recess Bolt <M6×1.0×12L>	2	2
11	400273	Compressing Wheel Axle <Ø8×55L>	1	1
12	200194	Chain Regulator <Ø10>	1	
	200195	Chain Regulator <Ø11.2>		1
13	200191	Chain Regulating Wheel <Ø39×25L>	1	
	200192	Chain Regulating Wheel <Ø40×28L>		1
14	400095	Spring Washer <M8>	6	6
15	400013	Hex. Recess Bolt <M8×1.25×25L>	4	4
16	207455	Chain Guide Ass'y	1	
	207498			1
17	207459	Chain Bucket <18#>	1	1
18	400233	Limit Spring <Ø10>	1	
	400234	Limit Spring <Ø11.2>		1
19	400543	Load Chain <Ø10>	9M	
	400544	Load Chain <Ø11.2>		9M
20	200201	Chain Stopper <Ø10>	2	
	200202	Chain Stopper <Ø11.2>		2
21	400014	Hex. Recess Bolt <M8×1.25×30L>	4	4
22	408351	Hex. Bolt <M12×1.75×135L>	1	1
23	400091	Lock Nut <M12×1.75>	1	1
24	207458	Washer <t5×Ø21×Ø31>	2	2

Electric Parts Drawing




Electric Parts B.O.M

S : Single Speed D : Dual Speed

Key No.	Parts Code	Description	Q'ty Req'd			
			3T		5T	
			S	D	S	D
1	400222	Cable Gland(M20)	1		1	
	400941	Cable Gland(M25)	1		1	
2	400053	Cross Headed Screw<M5 × 0.8 × 12L>	4		4	
3	400093	Spring Washer<M5>	7		7	
4	300343	Power Cable Holding Plate	1		1	
5		Power Cable Ass'y	1		1	
6	208668	Limit Switch Ass'y	1		1	
	208677			1		1
	208669	Limit Switch Ass'y (THA)	1	1	1	1
7	400620	Cross Headed Screw<M5 × 0.8 × 8L>	3		3	
8	300337	Electric Components Plate	1		1	
9	400094	Spring Washer<M6>	4		4	
10	400005	Hex. Recess Bolt<M6 × 1.0 × 12L>	4		4	
11	300340	P.E.R Holding Plate	1		1	
12	400092	Spring Washer<M4>	14		14	
13	400048	Cross Headed Screw<M4 × 0.7 × 6L>	13		13	
14	300332	Control Cable Holding Plate	1		1	
15	400271	Rubber Cap	1		1	
16	300342	Wire Holder Clamp	1		1	
17	400297	Wire Clip(3/16")	1		1	
18	301742	Single Speed Pbs	1		1	
	301981	Dual Speed Pbs		1		1
19	302376	Negative Phase Protector (N.P.P)	1		1	
20	302339	Terminal Block	6	8	6	8
21	300091	Contactor Rail	1		1	
22	300079	Contactor Rail	1		1	
23	300078	Contactor Rail	-	1	-	1
24	300800	Contactor Interlock	1		1	
25	301111	Magnetic Contactor <3A1a1b LC1-D18-E7>	2	3	2	3
26	300041	Magnetic Contactor <2A2B LC1-D258-E7>		1		1
27	301003	Transformer <PS-3L>	1		1	
	301015	Transformer <PS-10BR>		1		1
28	300726	Electric Overload(E.O)	1	2	1	2
29	300363	N.P.P/E.O Box	1		1	
30	300143	Rectifier		1		1
31	300995	Fuse Holder	2	2	2	2
32	300999	Fuse (3A)	2	2	2	2

Low Headroom Model's Drawing



Low Headroom Model's B.O.M

Key No.	Parts Code	Description	Q'ty Req'd	
			3T	5T
1	207389	Drive Frame Ass'y	1	
	207478			1
2	407808	Bearing <6207 Z >	8	
	400147	Bearing <6209 Z>		8
3	203134	Plain Wheel <Ø143.5 × 59>	2	
	207474	Plain Wheel <Ø176 × 60>		2
4	400194	Retaining Ring <S-35>	4	
	400196	Retaining Ring <S-45>		4
5	203114	Gear Wheel <M3.5 × 49T × 67>	2	
	207475	Gear Wheel <M3.5 × 49T × 76>		2
6	207383	Drive Frame Ass'y A	1	
	207469			1
7	207438	Stay Bolt <2" × 4 1/2UNC × 422>	2	
	207487	Stay Bolt <2" × 4 1/2UNC × 450>		2
8	207446	Spacer Sleeve <Ø95 × Ø52 × 8>	2	2
9	207488	Spacer Sleeve <Ø95 × Ø52 × 12.5>	8	8
10	400107	Spring Washer <2 ">	2	2
11	202018	Nut <2"-4 1/2UNC>	2	2
12	207445	Spacer Sleeve <Ø42 × Ø31.5 × 29.5>	1	
	207476	Spacer Sleeve <Ø60 × Ø41 × 21>		1
13	408052	Needle Bearing <TA 3020Z>	2	
	400174	Needle Bearing <TA 4025>		2
14	200170	Sprocket < Ø40 × 42L>	1	
	200111	Sprocket < Ø50 × 51L>		1
15	207444	Sprocket Axle <Ø30 × 108>	1	
	207477	Sprocket Axle <Ø40 × 108>		1
16	207437	Shaft Stopper <t5 × 66 × 66>	1	1
17	400094	Spring Washer <M6>	4	4
18	400006	Hex. Headed Bolt <M6 × 1.0 × 16>	4	4
19	207445	Spacer Sleeve <Ø42 × Ø31.5 × 29.5>	1	
	207492	Spacer Sleeve <Ø51 × Ø35.5 × 21>		1

Low Headroom Model's B.O.M

Key No.	Parts Code	Description	Q'ty Req'd	
			3T	5T
20	408052	Needle Bearing <TA 3020Z>	2	
	400836	Needle Bearing <HK 3520>		2
21	200170	Sprocket	1	
	207490			1
22	207439	Sprocket Axle <Ø30 × 182>	1	
	207489	Sprocket Axle<Ø35 × 195>		1
23	400101	Spring Washer < M24>	2	
	400652	Spring Washer < M30>		2
24	400076	Nut <M24 × 3.0>	2	
	400635	Nut <M30 × 3.5>		2
25	207440	Bushing <Ø51 × 24>	1	
	207491	Bushing <Ø55 × 24>		1
26	400313	Bumper	4	4
27	207428	Chain Connector <t52 × 131.5>	1	
	207467	Chain Connector <t52 × 131.5>		1
28	207441	Spacer Sleeve <Ø55 × Ø41 × 20>	1	1
29	207447	Chain Connecting Pin <Ø19 × 77>	1	
	207486	Chain Connecting Pin <Ø19 × 79>		1
30	207443	Chain Connector Axle <Ø40 × 108>	1	1
31	400091	Lock Nut <M12 × 1.75	1	1
32	207427	Stay Bolt <7/8" × 9UNC × 260>	2	2
33	400102	Spring Washer <7/8">	4	4
34	202016	Nut <7/8" × 9UNC>	4	4
35	207425	Counter Weight Block	8	8
36	203221	Spacer Washer <Ø40 × Ø24 × 1/8">	12	12
37	207434	Lock Pin <Ø20 × 60>	4	4
38	207432	Bracket	4	
	207485			4
39	207314	Shaft Stopper <t2 × Ø22 × Ø17>	8	8
40	207435	Guide Wheel <Ø40 × 37.5>	4	4
41	400190	Retaining Ring <S-16>	4	4

Low Headroom Model's B.O.M

Key No.	Parts Code	Description	Q'ty Req'd	
			3T	5T
42	400095	Spring Washer <M8>	16	16
43	400013	Hex. Headed Bolt <M8 × 1.25 × 25>	16	16
44	207430	Limit Steady	1	1
45	400662	Flat Washer <M6>	4	4
46	400006	Hex. Headed Bolt <M6 × 1.0 × 16>	4	4
47	301478	Limit Switch <TZ-5108-2>	1	1
48	400093	Spring Washer <M5>	4	4
49	405021	Hex. Headed Bolt <M5 × 0.8 × 35>	4	4
50	210330	Pinion <M3.5 × 16T>	2	2
51	101545	Motor Ass'y -B <0.4KW 50HZ 380V 4P>	2	2
52	300394	Electric Housing Cover	1	1
53	301102	Contactor <3A1a1b LC1-D09-E7 >	2	2
54	402583	Gasket 68#	1	1
55	400339	Rubber Cap	1	1
	400270		2	2
56	300395	Electric Housing	1	1
57	402516	Gasket 16#	1	1
58	400094	Spring Washer <M6>	6	6
59	400006	Hex. Recess Bolt <M6 × 1.0 × 16L>	6	6
60	207872	Limit Steady	1	1
61	300535	Limit Switch <ME-8108>	1	1
62	207951	Axle < Ø20 × 123>	2	2
63	207945	Spacer Sleeve C <Ø27 × Ø17 × 4>	2	
	207946	Spacer Sleeve C <Ø27 × Ø17 × 8>		2
64	207947	Chain Guide Plate	2	
	207949			2
65	207943	Spacer Sleeve B <Ø27 × Ø17 × 15>	2	2
66	207941	Spacer Sleeve A<Ø27 × Ø17 × 33>	2	
	207942	Spacer Sleeve A<Ø27 × Ø17 × 29>		2
67	400190	Retaining Ring <S-16>	2	2
68	408055	Needle Bearing <HK 1612>		8

The Standard Instruction and Inspection for Chain Block

The additional remarks quote from the standard regulations.

I Instructions: Please pay attention to the followings while using

- 1 · Ensure the conditions of the hoists and the ISO approval.
- 2 · The capacity should be within the normal capacity.
- 3 · Never use the load chain over standard. (above ISO 80)
- 4 · Always use the hoist when the lift height is standard.
- 5 · Keep daily inspection before using.
- 6 · Inspect the load chain and chain ring are free. Never lift a load when the chain is twisted.
- 7 · Never use the loose bottom hook.
- 8 · Never use the load chain without "Up" and "Down" device.
- 9 · Never use the chain to wrap the load.
- 10 · Never lift a load with the front of the hook.
- 11 · Never push the button switch
- 12 · Never lift a load over the limit lift height.
- 13 · Never stand under the raised load.
- 14 · Never slant a load over 15°C.
- 15 · Always avoid the hoist fall.
- 16 · Replace the load chain every year when the hoist is used frequently.
- 17 · Replace the load chain half a year and the bottom hook twice a year if the working environment temperature is above 100°C or below -40°C and the environment is corrosive and fracture.
Inspect the bottom hook and replace regularly when it's used frequently.
- 18 · Inspect the load chain monthly by electroplate or heat treatment manufacturers and replace it yearly.
- 19 · Never weld the load chain after broken.
- 20 · The load chain should be lubricated before using.
- 21 · Apply lubricant on the gear, bearing and other parts regularly.
- 22 · Prevent the hoist from rusting after infrequent use.
- 23 · Never modify the hoist by yourself. Please contact the original manufacturer to help you out.
- 24 · Never lift the same object with two hoists. If necessary, make sure the lifting should be operated within normal capacity.

Daily inspection

Electric Chain Hoist Daily Inspection Checklist

Series No.:

Hoist Model:

Date of Purchasing: / / (D/M/Y)

Unit:

Date: / /

No	Part	Item	Standard	V X	Y N
1	Motor	Outlook	The temperate controls within E level insulating temperate(135°C)		
2	Hook	Hook Throat Distortion Motion Others	The hook opening widens. The hook distorts. The hook spins smoothly. The hook breaks or dents.		
3	Load Chain	Elongate Wear Distort Corrode Break Lubricate Rotate	The elongation is over. The chain diameter is overused. The distortion is visible The chain corrodes. The load chain cracks. Apply lubricant (except grease). The weld joints face the same direction.		
4	Brake	The brake slips	The brake slips or creaks.		
5	Push Bottom Switch	Operation Outlook	The motion is as standard. The cover is broken or deformed.		
6	Limit Switch	Operation	The motion is correct.		
7	Wiring	Wiring Outlook	The wiring is loose. The wiring is broken or hard.		

Monthly inspection

Electric Chain Hoist Monthly Inspection Checklist

Series No.:

Hoist Model:

Date of Purchasing: / / (D/M/Y)

Unit:

Date: / /

No	Part	Item	Standard	V X	Y N
1	Limit Switch	Operate	Motion correct		
2	Hook	Hook Throat Distortion Motion Others	Opening Widens. Distorts. Spins Smoothly. Breaks or Dents.		
3	Load Chain	Elongate Wear Distort Corrode Break Lubricate	The elongation is over. The chain diameter is overused. The distortion is visible Corrodes. Cracks. Apply lubricant (except grease).		
4	Hex. Bolt	Everywhere	unwind		
5	Pendant Cable	outlook	Distortion		
6	Gear Box		Apply lubricant		

Yearly inspection

Electric Chain Hoist Yearly Inspection Checklist

Series No.:

Hoist Model:

Date of Purchasing: / / (D/M/Y)

Unit:

Date: / /

No	Part	Item	Standard	V X	Y N
1	Bearing	Outlook	Leak or breaks		
2	Gear	Outlook	Leak or breaks		
3	Oil seal	Outlook	Harden or leak of oil		
4	Ratch	Wear Distortion	Wear away over limit The distortion is visible		
5	Load Sheave	Wear Distortion	Wear away over limit The distortion is visible		
6	Guide Tube	Wear Distortion	Wear away over limit The distortion is visible		
7	brake	Action Wear Distort Other	Voice Wear away over limit The distortion is visible Leak or defects		
8	Hex. Bolt	Everywhere	unwind		
9	Lubricate	change	Add new oil		
10	Load test	Normal rated weight	Replay hang products up and down		